

RPP-PVC Polyurethane Gun Foam for PVC

Super low-pressure (with "low-expansion" formula), one-component polyurethane foam with applicator gun.

Product information



Applications

- Fixing pipes and cables in HVAC systems
- The application of PU foam: installation of windows and doors, filling, sealing, insulation in the construction industry
- Easy fixing of door and window frames timber, metal or PVC
- · Installation of windows and door
- Precise filling and sealing in the wide range of sizes gaps
- Thermal insulation of plumbing and central heating
- Installation & sealing of window sills
- Thermal insulation of roofing (including flat roofs)
- Filling gaps in the thermal insulation of buildings
- Filling frame structures

Features and benefits

- Low Expansion formulation (low growth) enables applications to narrow gaps, guarantees high yield (no wastes) and eliminates the risk of frame deformation
- Low-pressure formulation eliminates risk of frames deformation and ensures proper gaps filling
- Ideal for installation, sealing and soundproofing for PVC profiles
- Excellent sound and thermal insulation properties.
- Cutting time 40 min after apllication
- Excellent adhesion to most materials and substrates used in construction.
- · Resistant to mould and fungi.

Base materials

Approved for use in:

Installation guide















- 1. Wear protective gloves. Ensure surfaces are free from dust, dirt or debris.
- 2. Before using, make sure that the can temperature is above zero (optimum $+20^{\circ}$ C). Application temperature from $+5^{\circ}$ C up to $+30^{\circ}$ C.
- 3. Shake can vigorously for 30 seconds to mix properly components.
- 4. Screw gun onto the can. Hold can upside-down during application.
- 5. Moisten surfaces with water prior to application.
- 6. Fill gaps from down to up, zigzag motion, alternating from one wall to the other. Fill gaps to approximately 60 % volume. Max. wide of the gap 3-4 cm. Wider gaps should be applied after hardening of the previous layer. Each layer should be moistened with water using a spray.
- 7. After full curing, cut the excess foam with a knife and protect it from UV exposure by coating with plaster, paint, acrylic or silicone.
- 8. In the event of a stoppage exceeding five minutes duration, wipe the nozzle with cleaner for foam applicator.
- 9. After removing the applicator gun from the can, wipe down the nozzle and gun (internal and external surfaces) using a cleaner.

Technical Data

Parameter		Value	Methods	
Application temperature	[°C]	+5 ÷ +30		
Can temperature	[°C]	+20		
Efficiency	[dm³]	max. 45		
Colour	-	Light yellow		
Post-expansion	[%]	60		
Skin formation time	[min]	5 ÷ 12	20°C, RH 90%	
Pretreatment time	[min]	45	20°C, RH 90%	
Complete hardening time	[h]	24		
Fire resistance class	-	В3	DIN 4102	
Density	[kg/m ³]	19 ± 10	PN-EN ISO 845:2000	
Dimensional stability	[%]	≤3	40°C, RH 95%, 24 hrs	
Water absorption after 24h	[kg/m³]	≤1	PN-EN 1609:1999	
Tensile strength	[kPa]	≥ 100	PN-EN 1607:1999	
Compressive strength	[kPa]	≥ 40	PN-EN 826:1998	
Thermal resistance (upon hardening)	[°C]	-50 ÷ +90		
Thermal conductivity	[W/mK]	0,036		
Preparations solublity	-	Acetone, before hardening	Cleaner RPC-0500	
Soundproofing coefficient	[dB]	61	EN 12354-3	
Volume	[ml]	750		

Parameter		Value		
Shelf life [month]		15		
	-	upright position in an originally closed container		
		the storage temperature: from +5°C to +35°C (room temperature is recommended)		
Storage conditions		dry, cool and well-ventilated place away from direct sunlight and other sources heat and ignition		
		storing the product in conditions other than recommended may shorten the life time even by 3 months $$		

Product commercial data

	Product Code	Product Code Colour	lour Volume [ml]	Quantity [pcs]			Weight [kg]			Bar Codes
	Troduct code Color	Cotodi		Вох	Outer	Pallet	Вох	Outer	Pallet	Dai Codes
ĺ	RPP-PVC	Light yellow	750	12	12	672	10.8	10.8	636.5	5906675284064